

Photoelectric Dual Beam Detector User Manual (V2.2)



Güncel Türkçe Kullanım Klavuzlarının için
www.opaxteknikdestek.com adresini ziyaret ediniz.


◆ Thanks for purchasing photoelectric dual beam detector, please read the user manual carefully before installation.

WARNING	Do not use the product for purposes other than the detection of moving objects such as people and vehicles. Do not use the product to activate a shutter etc. which may cause an accident.
	Do not touch the unit base or power terminals of the product with a wet hand (do not touch when the product is wet with rain etc.) It may cause electric shock.
	Never attempt to disassemble or repair the product. It may cause fire or damage to the devices.
CAUTION	Do not exceed the voltage or current rating specified for any of the terminals during installation, doing so may cause damage to the devices.
	Do not pour water over the product with a bucket, hose etc. The water may enter which may cause damage to the devices.
	Clean and check the product periodically for safe use. If any problem is found, do not attempt to use the product as it is and have the product repaired by a professional engineer or electrician.

1.Features


- Interruption time or walkspeed adjustable
- NO / NC relay outputs
- Integrated tamper switch, turns on when cover is moved.
- Frequencies selectable for long distance and stacking installations
- LED display signal grading for easy alignment
- Wide voltage power input: DC9~30V/AC9~20V
- Waterproof grade: IP65
- Alignment angle horizontally $\pm 90^\circ$, vertically $\pm 10^\circ$
- Digital filtering, high environment adaptability to eliminate false alarms
- Integrated heating function, reliable in cold/frost/fog weather.

2.Part Description



3.Installation Notes

(1).Please avoid below situations to assure performance




(2).Normal installation


◆ Detection distance

Detection Distance	40m	60m	80m	100m
Beam Angle	1.1m	1.2m	1.8m	2.4m

◆ Mounting height




◆ Adjusting angle




Notice: For best testing results, please avoid testing in 45°

4.Setting Method

◆ Wall mounting



◆ Pole mounting




5.Connectors




Do not exceed the voltage or current rating specified for any of the terminals during installation.

Transmitter:



1. Power input: DC9~30V/AC9~20V
2. No heater in the package, please order if required.
3. Tamper switch (NC) is independent of the circuit, anti-tamper trigger when cover is removed.


Receiver:




1. Power input: DC9~30V/AC9~20V
2. No heater in the package, please order if require
3. Tamper switch (NC) is independent of the circuit, anti-tamper trigger when cover is removed.
4. C relay (30VDC 1.0A max).

6.Connecting Wires

(1).Single connect: Control panel operating voltage DC12V, NC alarm output. Connecting to power supply parallel




(2).Stacked connect: Control panel operating voltage DC12V,NC alarm output series connect



(3).2 pairs install in series: Connect power of transmitter and receiver in series with 12V DC on power supply. Alarm output is N.C.

As below:



◆ Wiring distance between the power supply and the detector should not exceed the following table length.


Wire diameter	Voltage	DC12V	DC24V
Length			
0.5mm ² (Φ0.8)		400m	2000m
0.75mm ² (Φ1.0)		600m	3000m
1.0mm ² (Φ1.2)		800m	4000m
1.5mm ² (Φ1.4)		1000m	5000m




- Warning**
1. The power wire can't exceed the listed length.
 2. When connecting multiple detectors, the required cable length is divided by the corresponding number of units listed.
 3. Don't connect the port with the voltage or current which is over the normal specification.

7. DIP Switch Explanations

DIP switch show on the left side of the main PCB, as shown in following figure.



- DIP switches 1&2: Set beam frequency. TX and RX must be the same.
- DIP switch 3: Set heater. Preheat is for test. If the heater is installed, keep it on Heat position for normal use.




- DIP switches 1&2: Set beam frequency. TX and RX must be the same.
- DIP switch 3: Set heater. Preheat is for test. If the heater is installed, keep it on Heat position for normal use.
- DIP switches 4&5: Set interruption time. 50/100/300/700ms optional.

8. Optic Axis Adjustment

1. Set TX and RX same frequency by DIP switches 1&2.
2. Adjust the beams vertically and horizontally, it is well aligned if LED shows "99".
3. Do "walk test" to ensure it'll activate alarm normally. If failed, please re-do alignment. If alignment keeps failing, please refer to troubleshooting.

Signal strength	
00~40	Realign
41~70	Fair
71~90	Good
91~99	Best



9. Walk Test

<p>Alarm Status</p>	Please make sure the alarm indicator is off before testing. If not, redo the alignment.
<p>Transmitter Receiver</p>	Please do the test at the 3 following positions 1. At the transmitter side 2. At the receiver side 3. In the middle
<p>Alarm Status</p>	Alarm indicator turns on when beam is interrupted, test finished successfully.

Note: If the alarm LED indicator is OFF even though the beams are completely blocked, refer to the "Trouble Shooting".

10. Troubleshooting

Symptom	Possible cause	Remedy
Power on, but power LED off	1. No voltage on power cable; 2. Broken circuit or short circuit; 3. Beyond specified voltage; 4. Power cable exceeds the specified length	1. Check PSU, voltage, cables and connectors
When beam is blocked, the alarm LED does not indicate, nor does the alarm relay switch	1. There is reflection or cross-talk from other transmitters 2. Walk speed set too long 3. Alarm output cable is shorted or damaged	1. Change beam path or change TX/RX frequency channel 2. Ensure 2 beams all blocked 3. Change walk-speed setting 4. Check RX terminal and output cable
When beam is not blocked, alarm LED indicates activation	1. Beam is out of alignment; optical axis does not overlap 2. There are objects between TX and RX 3. Frequency is incorrect 4. The cover is dirty or capped by snow, frost and ice 5. TX is faulty or OFF	1. Adjust optical axis 2. Check objects between TX and RX 3. Ensure the frequency of TX and RX is the same 4. Clean cover or user heater 5. Check the voltage or wiring of TX
False alarm	1. Bad wiring and fluctuant power voltage 2. Randomly blocked, like birds, paper or leaves 3. The beams base is unstable 4. Out of alignment	1. Check power, current and wiring voltage 2. Change installation location 3. Strengthen installation base 4. Re-align

11. Specifications

Detection distance	Outdoor	40m	60m	80m	100m
	Indoor	120m	180m	240m	300m
Detection distance(max)		250m	350m	500m	600m
Detection method	Simultaneous interruption of 2 infrared beams				
Interruption time	50ms, 100ms, 300ms, 700ms (adjustable)				
Frequencies	4 different frequencies (selectable)				
Power and voltage	DC9~30V/AC9~20V				
Current consumption	70mA max	75mA max	80mA max	85mA max	
Alarm cycle	≥1.5s				
Alarm output	1C. relay output (AC/DC30V, 1.0A max)				
Tamper	NC. works when cover is removed				
IP rating	IP65				
Operating temperature	-25°C ~ 55°C				
Humidity	95% max				
Correction angle	Horizontal 180°(±90°), Vertical 20°(±10°)				
Install location	Indoor/Outdoor, Wall/Pole				
Weight	1000g				
Attachment	U bracket	2pcs, 70.4*37.5*21.5mm, δ=1.5mm, stainless steel			
	Pole mounting screw	4pcs, PM4*30mm			
	Wall mounting screw	4pcs, PM4*25mm			
	Expansion pipe	4pcs, Φ7*27mm, green			
	Installation paper	2pcs, W85*H220mm			
Heaters (additional purchase)	Voltage	DC9~30V/AC9~20V			
	Current	200mA max			
	Temperature	+60°C			
	Working condition	Auto Heating when it's ≤5°C and stop heating when it's ≥7°C			

Note: When environment temperature lower than -20°C, please use heaters to ensure normal working. Heater is non-polarized.

12. Dimensions

